

Handbook for
■ DNA micro

TOTAL DNA PURIFICATION KIT



Customer & Technical Support

Do not hesitate to ask us any question.

We thank you for any comment or advice.

Contact us at

www.geneall.com

Tel : 82-2-407-0096

Fax : 82-2-407-0779

E-mail(Order/Sales) : sales@geneall.com

E-mail(Tech. Info.) : bnp@geneall.com

Visit GeneAll® Community

www.geneall.com

www.geneall.co.kr

Trademarks

AmpONE™, Exfection™, Exgene™, Expin™, Exprep™, EzClear™, EzSep™, GenEx™, Hybrid-Q™, DirEx™, RiboEx™, Riboclear™, Ribospin™ are trademarks of GeneAll Biotechnology co., ltd.

© 2011 | GeneAll Biotechnology, all right reserved.

This protocol handbook is included in :

GeneAll® Exgene™ Genomic DNA micro (118-050)

Visit www.geneall.com or www.geneall.co.kr for FAQ, QnA and more information.

INDEX

	Kit contents	04
	Precautions and disclaimer	05
	Storage Condition	
	Quality Control	
	Chemical Hazard	
	General Handling	06
	Carrier RNA	
	Additional equipments or materials to be supplied by user	
	Introduction	07
	PCR Amplification	
	Real-time PCR Amplification	
	Kit Procedures	08
	Protocol for..	
	Small volumes of Blood	09
	Swab (blood, saliva or sperm)	11
	Body fluid stains (blood, saliva or semen)	13
	Hair and nail clippings	15
	Bones and Teeth	17
	Cigarette butts	20
	Tooth brush	22
	Tissue	24
	Urine	26
	Chewing gum	28
	Troubleshooting Guide	30
	Ordering Information	32

KIT CONTENTS

Exgene™ Genomic DNA micro	
Cat. No.	118-050
Size	micro
No. of preparation	50
Micro column type S with collection tube	50
Collection tube	100
Buffer CL	25 ml
Buffer BL	25 ml
Buffer BW	30 ml
Buffer TW	50 ml
Buffer AE*	15 ml
Carrier RNA	60 ug
Proteinase K	24 mg
PK storage bfr.	1.2 ml
Protocol Handbook	1

* 10mM Tris-HCl, pH 9.0, 0.5mM EDTA

Precautions and Disclaimer

GeneAll® Exgene™ Genomic DNA micro kit is for research use only, and should not be used for drug, household or other unintended uses. All due care and attention should be taken in every procedure in this handbook. Please consult the Material Safety Data Sheet (MSDS) for information regarding hazard and safe handling practices.

Storage Condition

All components of GeneAll® Exgene™ Genomic DNA micro kit should be stored at room temperature (15 ~ 25°C). After reconstitution of proteinase K with storage buffer, it should be stored under 4°C for conservation of activity. It can be stored at 4°C for 1 year without significant decrease in activity. But for prolonged preservation of activity, storing under -20°C is recommended.

Under cool ambient condition, a precipitate can be formed in buffer CL and/or BL. In such a case, heat the bottle above 37°C to dissolve completely. GeneAll® Exgene™ Genomic DNA micro kit is guaranteed until the expiration date printed on the product label.

Quality Control

All components in GeneAll® Exgene™ Genomic DNA micro kit is manufactured in strictly clean condition, and its degree of cleanness is monitored periodically. Restriction enzyme assay, PCR amplification assay and spectrophotometric assay as quality control are carried out from lot-to-lot thoroughly, and only the qualified is approved to be delivered.

Chemical Hazard

Buffer BL and BW contain irritant which is harmful when in contact with skin or eyes, or when inhaled or swallowed. Care should be taken during handling. Always wear gloves and eye protector, and follow standard safety precautions.

General handling

When working with small-size samples, microbiological aseptic technique should be always used for prevention of contamination by microbe and other contaminants.

Always wear disposable gloves while handling reagents and samples. Also, we recommend the use of sterile tip, tube and other instruments.

Carrier RNA

This kit is provided with carrier RNA, which can be added to Buffer BL if required. Carrier RNA enhances binding of DNA to the micro column membrane, especially if there are very few target molecules in the sample.

For purification of DNA from very small amounts of sample, we recommend adding carrier RNA to Buffer BL. To obtain a solution of 1 ug/ul, add 60 ul of Buffer AE to the tube containing 60 ug lyophilized carrier RNA. Dissolve the carrier RNA thoroughly, divide it into conveniently sized aliquots, and store at -20°C. Don't freeze-thaw the aliquots of carrier RNA more than 3 times. For one DNA preparation, 1 ul of dissolved carrier RNA is required.

Additional equipments or materials to be supplied by user


- Sterile microcentrifuge tube
- Centrifuge
- Water bath or heating block
- Ethanol (96 ~ 100 %)
- 1M Dithiothreitol (DTT)
- SPEX Freezer Mill[®] or metal blender for bones and teeth
- Other general lab equipments

INTRODUCTION

The GeneAll® Exgene™ Genomic DNA micro kit provides fast and easy methods for the micro scale purification of total (genomic and mitochondrial) DNA from various biological samples. Purified DNA can be used directly for PCR, quantitative PCR, genotyping such as STR analysis and other downstream applications.

GeneAll® Exgene™ Genomic DNA micro kit utilizes the advanced silica-binding technology to purify total DNA sufficiently pure for many applications. Various samples are lysed in optimized buffer containing detergents and lytic enzyme. Under high salt condition, DNA in the lysate bind to silica membrane and impurities pass through membrane into a collection tube. The membranes are washed with a series of alcohol-containing buffer to remove any traces of proteins, cellular debris and salts. Finally pure DNA is released into a clean collection tube with deionized water or low ionic strength buffer.


PCR Amplification



PCR reaction was performed with purified DNA using GeneAll® Exgene™ Genomic DNA micro kit. Template was isolated from whole blood (Lane 1), dried blood spot (Lane 2), hair root (Lane 3), chewing gum (Lane 4), animal tissue (Lane 5), urine (Lane 6), bone (Lane 7) and hair shaft (Lane 8).

M : 1 Kb ladder

Real-time PCR Amplification



Real-time PCR was performed with purified DNA using GeneAll® Exgene™ Genomic DNA micro kit. The DNA was extracted from whole blood, stains, swab and hair root (Panel 1), nail clippings, chewing gum, tooth brush and urine (Panel 2). Real-time PCR was carried out with human GAPDH primer sets, and detected by SYBR® Green.

KIT PROCEDURES

in microcentrifuges

Starting samples



Lyse



Bind



1st Wash
with BW



2nd Wash
with TW



Elute



Pure genomic DNA

A.

PROTOCOL FOR.

Small Volumes of Blood

Before experiment

Prepare the water bath 56°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath.



- 1. Pipet 10 ul of Proteinase K solution into the bottom of a 1.5 ml microcentrifuge tube.**
- 2. Transfer 1 ~ 100 ul of whole blood to the tube.**

If the whole blood volume is less than 100 ul, adjust the volume to 100 ul with Buffer CL.
- 3. Add 100 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 56°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.
If the volume of blood is lower than 10 ul, recommend adding carrier RNA to Buffer BL.
- 4. Add 100 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.



- 5. Transfer the mixture to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.

B.

PROTOCOL FOR.

Swab (blood, saliva or sperm)

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath


B

- 1. Place the swab in a 1.5 ml microcentrifuge tube.**
- 2. Add 300 ul of Buffer CL and 20 ul of proteinase K. Vortex the tube to mix thoroughly. Incubate the tube at 56°C for 1 h. Spin down briefly to remove any drops from inside of the lid.**

If processing semen swab, add 20 ul of 1M DTT as well.
For efficient lysis, mix the sample completely. To help the efficient lysis, vortex the tube every 10 min during the incubation.
- 3. Add 300 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.
If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.
- 4. Add 300 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.

- 
- 5. Transfer the mixture to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture is remained, apply the mixture twice; apply 700 ul of the mixture, spin down, discard the pass-through, re-insert empty collection tube, and repeat this step again until all of the mixture has applied to the micro column.

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.

C.

PROTOCOL FOR.

Body Fluid Stains (blood, saliva or semen)

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature


Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

- 1. Place 0.5 cm² of punched-out circles from stained materials into a 1.5 ml microcentrifuge tube.**
- 2. Add 200 ul of Buffer CL and 20 ul of proteinase K. Vortex the tube to mix thoroughly. Incubate the tube at 56°C for 1 h. Spin down briefly to remove any drops from inside of the lid.**

If processing semen stains, add 20 ul of 1M DTT as well.
For efficient lysis, mix the sample completely. To help the efficient lysis, vortex the tube every 10 min during the incubation.
- 3. Add 200 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.
If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.
- 4. Add 200 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.

- 
- 5. Transfer the supernatant to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.

D.

PROTOCOL FOR.

Hair and Nail Clippings

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

- 1. Collect hair (root or shaft) or nail clippings sample in a 1.5 ml microcentrifuge tube.**
- 2. Add 200 ul of Buffer CL, 20 ul of proteinase K and 20 ul of 1M DTT, vortex to mix and incubate the tube at 56°C for at least 1 h until the sample is dissolved. Spin down briefly to remove any drops from inside of the lid.**


For efficient lysis, mix the sample completely. To help the efficient lysis, vortex the tube every 10 min during the incubation.

For nail clippings, it is recommended to incubate overnight incubation at 56°C.

- 3. Add 200 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.

If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.

- 
- 4. Add 200 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.

- 5. Transfer the supernatant to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.

E.

PROTOCOL FOR.

Bones and Teeth

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

I. Disrupt the bones or teeth using one of the described methods.

- The use of the SPEX Freezer Mill®


Transfer the small fragment of bones or teeth and the ball into a grinding vial. Put the vial into Freezer Mill then pour liquid nitrogen. Grind the bone or teeth until the sample is pulverized completely.

- The use of the metal blender

Crush the bones or teeth into small fragment. Grind to a fine powder using a metal blender half-filled with liquid nitrogen.

- The use of EDTA

Transfer the bones or teeth into centrifuge tube. Pour the 0.5 M EDTA to sink the sample. Incubate the sample for decalcification at room temperature until the sample become flexible (for several days or even weeks, depending on the size of the bones or teeth). Change the EDTA occasionally during incubation. Cut the sample as small as possible with a microtome or blade.

- 
2. **Place up to 100 mg of bones or teeth into a 1.5 ml microcentrifuge tube.**
 3. **Add 300 ul of Buffer CL and 20 ul of proteinase K, vortex to mix. Incubate overnight at 56°C. Spin down briefly to remove any drops from inside of the lid.**

For efficient lysis, recommend to lyse using rotator within incubator.

4. **Add 300 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.

If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.

5. **Centrifuge the tube at full speed for 1 min, and carefully transfer the supernatant to a new 1.5 ml microcentrifuge tube.**

6. **Add 300 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.

7. **Transfer the mixture to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture is remained, apply the mixture twice; apply 700 ul of the mixture, spin down, discard the pass-through, re-insert empty collection tube, and repeat this step again until all of the mixture has applied to the micro column.

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 8. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 9. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 10. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 11. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.



F.

PROTOCOL FOR.

Cigarette Butts

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

- 1. Cut out a 1 cm² piece of outer paper from the end of the cigarette or filter. Cut this piece into 6 smaller pieces. Transfer the pieces to a 1.5 ml microcentrifuge tube.**

Wear gloves and use sterile scissors or scalpel.

- 2. Add 300 ul of Buffer CL and 20 ul of proteinase K, vortex to mix. Incubate the tube at 56°C for 1 h. Spin down briefly to remove any drops from inside of the lid.**

For efficient lysis, mix the sample completely. To help the efficient lysis, vortex the tube every 10 min during the incubation.

- 3. Add 300 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.

If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.

- 4. Add 300 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.



- 5. Transfer the supernatant to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture is remained, apply the mixture twice; apply 700 ul of the mixture, spin down, discard the pass-through, re-insert empty collection tube, and repeat this step again until all of the mixture has applied to the micro column.

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.

G.

PROTOCOL FOR.

Tooth Brush

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

1. Collect bristles on tooth brush in a 1.5 ml microcentrifuge tube.

Alternatively, rinse the tooth brush with 10 ml of 1x PBS. Collect the buccal cells by centrifugation.

2. Add 200 ul of Buffer CL and 20 ul of proteinase K, vortex to mix. Incubate the tube at 56°C for 1 h. Spin down briefly to remove any drops from inside of the lid.

For efficient lysis, mix the sample completely. To help the efficient lysis, vortex the tube every 10 min during the incubation.

3. Add 200 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.

It is essential to mix the sample and buffer BL thoroughly for good result. If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.

4. Add 200 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.

It is important to mix the sample and ethanol completely for good result.



- 5. Transfer the supernatant to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.

H.

PROTOCOL FOR.

Tissue

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

- 1. Transfer less than 10 mg of a tissue sample to a 1.5 ml microcentrifuge tube.**
- 2. Add 200 ul of Buffer CL and 20 ul of proteinase K. Mix completely by vortexing or pipetting. Incubate the tube at 56°C until the sample is completely lysed. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the components completely for proper lysis. The lysate should become translucent without any particles after complete lysis.

To help the efficient lysis, vortex the tube occasionally (2 ~ 3 times per hour) during the incubation.

- 3. Add 200 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.

If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.

- 4. Add 200 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.

- 5. Transfer the mixture to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.



I.

PROTOCOL FOR.

Urine

Before experiment

Prepare the water bath 56°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

- 1. Transfer up to 1 ml urine to a 1.5 ml microcentrifuge tube and centrifuge for 2 min at 6,000 xg above (>8,000 rpm).**
- 2. Discard the supernatant. Add 200 ul of 1x PBS then vortex the tube for 5 sec.**
- 3. Centrifuge for 2 min at 6,000 xg above (>8,000 rpm). Then discard the supernatant.**
- 4. Add 200 ul of Buffer CL and 20 ul of proteinase K. Vortex to mix. Incubate the tube at 56°C for 1 h. Spin down briefly to remove any drops from inside of the lid.**

Since urine can contain sperm cells, add 20 ul of 1M DTT as well.

For efficient lysis, mix the sample completely. To help the efficient lysis, vortex the tube every 10 min during the incubation.

- 5. Add 200 ul of Buffer BL and 200 ul of absolute ethanol (not provided) to the tube. Vortex the tube to mix thoroughly. Spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample, buffer BL and ethanol completely for good result.

If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.

- 6. Transfer the mixture to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 7. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 8. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 9. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 10. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.

J.

PROTOCOL FOR.

Chewing Gum

Before experiment

Prepare the water bath 56°C and 70°C

Prepare absolute ethanol

Prepare 1.5 ml microcentrifuge tube

Equilibrate buffer AE to room temperature

All centrifugation should be performed at room temperature

Buffer BL and CL may precipitate at cool ambient temperature. If so, dissolve it in 56°C water bath

- 1. Cut up to 30 mg of chewing gum into small pieces and them to a 1.5 ml microcentrifuge tube.**

Wear gloves and use sterile blade or scalpel.

- 2. Add 300 ul of Buffer CL and 20 ul of proteinase K. Mix completely by vortexing or pipetting. Incubate the tube at 56°C for 3 h. Spin down briefly to remove any drops from inside of the lid.**

For efficient lysis, mix the sample completely. To help the efficient lysis, vortex the tube every 30 min during the incubation.

- 3. Add 300 ul of Buffer BL to the tube. Vortex the tube to mix thoroughly. Incubate the tube at 70°C for 10 min. Spin down briefly to remove any drops from inside of the lid.**

It is essential to mix the sample and buffer BL thoroughly for good result.

If carrier RNA is required, add the dissolved carrier RNA to Buffer BL.

- 4. Add 300 ul of absolute ethanol (not provided) to the sample, pulse vortex to mix the sample thoroughly, and spin down briefly to remove any drops from inside of the lid.**

It is important to mix the sample and ethanol completely for good result.

- 5. Transfer the supernatant to the column carefully, centrifuge for 1 min at 6,000 xg above (>8,000 rpm), and replace the collection tube with new one (provided).**

If the mixture remain, apply the mixture twice; apply 700 ul of the mixture, spin down, discard the pass-through, re-insert empty collection tube, and repeat this step again until all of the mixture has applied to the micro column.

If the mixture has not passed completely through the membrane, centrifuge again at full speed (> 13,000 xg) until all of the solution has passed through.

Centrifugation at full speed will not affect DNA recovery.

- 6. Add 500 ul of Buffer BW, centrifuge for 1 min at 6,000 xg above (>8,000 rpm) and replace the collection tube with new one (provided).**

Centrifugation at full speed will not affect DNA recovery.

- 7. Apply 700 ul of Buffer TW. Centrifuge for 1 min at 6,000 xg above (>8,000 rpm). Discard the pass-through and reinsert the column back into the collection tube.**

Centrifugation at full speed will not affect DNA recovery.

- 8. Centrifuge at full speed for 3 min to remove residual wash buffer. Place the column in a fresh 1.5 ml tube (not provided).**

Care must be taken at this step for eliminating the carryover of buffer TW. If carryover of buffer TW still occurs, centrifuge again for 3 min at full speed with the collection tube before transferring to a new 1.5 ml tube. Centrifugation must be performed at full speed (13,000 xg ~ 20,000 xg).

- 9. Add 20 ~ 50 ul of Buffer AE or sterilized water. Incubate for 1 min at room temperature. Centrifuge at full speed for 1 min.**

Ensure that the buffer AE or sterilized water is dispensed directly onto the center of column membrane for optimal elution of DNA.



Troubleshooting Guide

Facts	Possible Causes	Suggestions
Low or no yield	Starting material is too old or mis-stored	Best yield will be obtained from fresh sample. DNA yield is dependent on the type, size, age and storage of starting material. Lower yield will be obtained from material that has been inappropriately stored. For example, blood samples that have been stored at 4°C for more than 5 days may bring about reduced yield.
	Inefficient or insufficient lysis	Inefficient lysis may be due to several causes; - Insufficient mixing with buffer BL - Degenerated Proteinase K After addition of buffer BL in protocol, vortex the mixture vigorously and immediately to mix completely. Proteinase K should be stored under 4°C for maintenance of proper activity. However, it is recommended to store in small aliquots at -20°C for prolonged preservation of its activity.
	Improper eluent	As user's need, elution buffer other than buffer AE can be used. However, the condition of optimal elution should be low salt concentration with alkaline pH ($7 < \text{pH} < 9$). When water or other buffer was used as eluent, ensure that condition.
	Cell clumps present in the lysate	Cell clumps will remain until cells are completely lysed. Incomplete lysis of cells will bring about poor yield. To lyse completely the cells in the clumps, incubate sample at either 37°C or room temperature with periodic mixing until the solution is homogeneous.

Facts	Possible Causes	Suggestions
DNA floats out of well while loading of agarose gel	Residual ethanol from Buffer TW remains in eluate	Ensure that the TW wash step in protocol has been performed correctly. Micro column membrane should be completely dried via additional centrifugation or air-drying. Refer the annotation of TW washing step.
Enzymatic reaction is not performed well with purified DNA	Residual ethanol remains in eluate	Determine the maximum volume of eluate suitable for your amplification reaction. Reduce or increase the volume of eluate added to the amplification reaction accordingly. The elution volume can be adjusted proportionally.
	High salt concentration in eluate	Ensure that all washing steps were performed just in accordance with the protocols. Alternatively, carry out additional washing step with buffer TW. It may help remove high salt in eluate.
Column clogging	Inefficient lysis	Inefficient lysis may lead to column clogging. About inefficient lysis, check 'Inefficient lysis' at "Low or no yield"
Precipitate in Buffer CL or BL	Buffer stored in cool ambient condition	For proper DNA purification, any precipitate in buffer CL/BL should be dissolved by incubating the buffer at 37°C or above until it disappears.

Ordering Information

Products	Size	Type	Cat. No.
GeneAll® Hybrid-Q™ for rapid preparation of plasmid DNA			
Plasmid Rapidprep	50	mini / spin	100-150
	200		100-102
GeneAll® Exprep™ for preparation of plasmid DNA			
Plasmid SV mini	50	spin / vacuum	101-150
	200		101-102
	1,000		101-111
Plasmid SV Midi**	26	spin / vacuum	101-226
	50		101-250
	100		101-201
Plasmid SV Quick	50	mini / spin	101-050
	200		101-002
	1,000		101-011
GeneAll® Exfection™ for preparation of highly pure plasmid DNA			
Plasmid LE mini (Low Endotoxin)	50	spin / vacuum	111-150
	200		111-102
Plasmid LE Midi* (Low Endotoxin)	26	spin / vacuum	111-226
	100		111-201
Plasmid EF Midi* (Endotoxin Free)	20	spin	121-220
	100		121-201
GeneAll® Expin™ for purification of fragment DNA			
Gel SV	50	mini / spin / vacuum	102-150
	200		102-102
PCR SV	50	mini / spin / vacuum	103-150
	200		103-102
CleanUp SV	50	mini / spin / vacuum	113-150
	200		113-102
Combo GP	50	mini / spin / vacuum	112-150
	200		112-102
GeneAll® Exgene™ for isolation of total DNA			
Tissue SV mini (plus!)*	100	spin / vacuum	104(9)-101
	250		104(9)-152
Tissue SV Midi (plus!)**	26	spin / vacuum	104(9)-226
	100		104(9)-201
Tissue SV MAXI (plus!)**	10	spin / vacuum	104(9)-310
	26		104(9)-326
Blood SV mini	100	spin / vacuum	105-101
	250		105-152
Blood SV Midi**	26	spin / vacuum	105-226
	100		105-201
Blood SV MAXI**	10	spin / vacuum	105-310
	26		105-326

Products	Size	Type	Cat. No.
GeneAll® Exgene™ for isolation of total DNA			
Cell SV mini	100	spin / vacuum	106-101
	250		106-152
Cell SV MAXI**	10	spin / vacuum	106-310
	26		106-326
Clinic SV mini	100	spin / vacuum	108-101
	250		108-152
Clinic SV Midi	26	spin / vacuum	108-226
	100		108-201
Clinic SV MAXI**	10	spin / vacuum	108-310
	26		108-326
Genomic DNA micro	50	spin	118-050
Plant SV mini	100	spin / vacuum	117-101
	250		117-152
Plant SV Midi**	26	spin / vacuum	117-226
	100		117-201
Plant SV MAXI**	10	spin / vacuum	117-310
	26		117-326
GMO SV mini	50	spin / vacuum	107-150
	200		107-102
GeneAll® GenEx™ for isolation of total DNA			
GenEx™ B	100 [†]	mini / solution	220-101
	500 [†]	mini / solution	220-105
	100 ^{††}	MAXI / solution	220-301
GenEx™ C	100 [†]	mini / solution	221-101
	500 [†]	mini / solution	221-105
	100 ^{††}	MAXI / solution	221-301
GenEx™ T	100 [†]	mini / solution	222-101
	500 [†]	mini / solution	222-105
	100 ^{††}	MAXI / solution	222-301
GeneAll® DirEx™ Single tube DNA extraction buffer for PCR			
DirEx™	50	solution	250-050

* GeneAll® Tissue SV mini, Midi, and MAXI plus! kit provide the additional methods for the purification from animal whole blood.

** GeneAll® SV Midi / MAXI kits require the centrifuge which has a swinging-bucket rotor and ability of 4,000 ~ 5,000 xg.

† On the basis of DNA purification from 300 ul whole blood, 2×10^6 cells or 10 mg animal tissue.

†† On the basis of DNA purification from 10 ml whole blood, 1×10^8 cells or 100 mg animal tissue.

Ordering Information

Products	Size	Type	Cat. No.
GeneAll® RiboEx™ for preparation of total RNA			
RiboEx™	100	solution	301-001
	200		301-002
Hybrid-R™	100	spin	305-150
RiboEx™ LS	100	solution	302-001
	200		302-002
Riboclear™	50	spin	303-150
Ribospin™	50	spin	304-150
Ribospin vRD™	50	spin	302-150
Allspin™	50	spin	306-150
GeneAll® AmpONE™ for PCR amplification			
Taq DNA polymerase	250 U	(2.5 U/μℓ)	501-025
	500 U		501-050
	1,000 U		501-100
α-Taq DNA polymerase	250 U	(2.5 U/μℓ)	502-025
	500 U		502-050
	1,000 U		502-100
Pfu DNA polymerase	250 U	(2.5 U/μℓ)	503-025
	500 U		503-050
	1,000 U		503-100
Hotstart Taq DNA polymerase	250 U	(2.5 U/μℓ)	531-025
	500 U		531-050
	1,000 U		531-100
Clean Taq DNA polymerase	250 U	(2.5 U/μℓ)	551-025
	500 U		551-050
	1,000 U		551-100
Clean α-Taq DNA polymerase	250 U	(2.5 U/μℓ)	552-025
	500 U		552-050
	1,000 U		552-100
Taq Master mix	2x	0.5 ml x 2 tubes	511-010
	2x	0.5 ml x 10 tubes	511-050
α-Taq Master mix	2x	0.5 ml x 2 tubes	512-010
	2x	0.5 ml x 10 tubes	512-050

* GeneAll® Tissue SV mini, Midi, and MAXI plus! kit provide the additional methods for the purification from animal whole blood.

** GeneAll® SV Midi / MAXI kits require the centrifuge which has a swinging-bucket rotor and ability of 4,000 – 5,000 xg.

† On the basis of DNA purification from 300 μl whole blood, 2 x 10⁶ cells or 10 mg animal tissue.

†† On the basis of DNA purification from 10 ml whole blood. 1 x 10⁶ cells or 100 mg animal tissue.

Products	Size	Type	Cat. No.
GeneAll® AmpONE™ for PCR amplification			
Taq Premix	20 μl	96 tubes	521-200
	50 μl		521-500
α -Taq Premix	20 μl	96 tubes	522-200
	50 μl		522-500
Taq Premix (w/o dye)	20 μl	96 tubes	524-200
α -Taq Premix (w/o dye)	20 μl	96 tubes	525-200
dNTP mix	500 μl	2.5 mM each	509-020
dNTP set (set of dATP, dCTP, dGTP and dTTP)	1 ml x 4 tubes	100 mM	509-040

* Each dNTP is available



www.geneall.com

Banseok Bld., 128 Oguem-dong,
Songpa-gu, Seoul, KOREA 138-859

E-MAIL sales@geneall.com

T E L 82-2-407-0096

F A X 82-2-407-0779

©2011 GeneAll Biotechnology, All right reserved

Edited by Kim Yang Seop
Designed by Joo Sang Mi